



electronic rebuilders

a division of National Parts Distributing Ltd

trouble shooting tips

No. 21 - Installing C2000 Progressive International Consoles

Published: May 2002

To avoid communication and Totalizer Problems when installing C2000 Progressive International Consoles, perform a Master reset on the Console, and on the Pumps you are connecting it to, before programming the Console and putting it on line.

Note! The console must be on line and communicating with the pumps before programming it!